

FILM-TECH

THE INFORMATION CONTAINED IN THIS ADOBE ACROBAT PDF FILE IS PROVIDED AT YOUR OWN RISK AND GOOD JUDGMENT.

THESE MANUALS ARE DESIGNED TO FACILITATE THE EXCHANGE OF INFORMATION RELATED TO CINEMA PROJECTION AND FILM HANDLING, WITH NO WARRANTIES NOR OBLIGATIONS FROM THE AUTHORS, FOR QUALIFIED FIELD SERVICE ENGINEERS.

IF YOU ARE NOT A QUALIFIED TECHNICIAN, PLEASE MAKE NO ADJUSTMENTS TO ANYTHING YOU MAY READ ABOUT IN THESE ADOBE MANUAL DOWNLOADS.

WWW.FILM-TECH.COM

CP650-DOLBY DIGITAL SURROUND EX CONNECTIONS

With the Cat. No. 794 Dolby Digital Surround EX board installed, the CP650 outputs to all surround channels appear at the **Option I/O Card** connector on the rear panel of the CP650. The left surround and right surround channel output wiring must be moved from the **Main Audio Output** connector to this connector. **Do not** use the Ls and Rs outputs on the main audio output connector. Additionally, install the wiring for the new back surround channel amplifiers.

