Fil m-Tech

The information contained in this Adobe Acrobat pdf file is provided at your own risk and good judgment.

These manuals are designed to facilitate the exchange of information related to cinema projection and film handling, with no warranties nor obligations from the authors, for qualified field service engineers.

If you are not a qualified technician, please make no adjustments to anything you may read about in these Adobe manual downloads.


www.film-tech.com


Kabel- und Anschlußpläne ERNEMANN 15 Cable- and Connection diagrams ERNEMANN 15


- Blatt/Page 1. E15 35/16 CP65 2 Projektoren (2 projectors)
- Biatt/Page 2. E15 35/16 CP65
- Blatt/Page 3. Ernemann 35/16 Ton (35/16 sound)
- Blatt/Page 4. E15 Netz (power supply)
- Blatt/Page 5. E15 Überblendung (change over)
- Blatt/Page 6. Projektorwerk E15 (projectorhead)
- Blatt/Page 7. E15 Fernbedienung (remote control)
- Blatt/Page 8.
- Blatt/Page 9. Schalterbelegung
 Steuerelektronik E15
 (DIP switches control PCB)


Blatt/Page 10.


Blatt/Page 11. E 15 35/16 CP 65/DA 20
Laser Audio Sound
Steckerbelegung/ Anschlußplan
Plug connection/ Wiring diagram
INHALT/KINO/KK/TW




















Schalterbelegung Steuerelektronik ERNEMANN 15

Nr. 37-095.05 STE 15

V.

Programm 5C31

Dipschalter B3,1 - B3,8

NO	Impuls Impuls 3 Min. 3 Min. Impuls Min. Impuls Motor Ein Normal
OFF	Kein Impuls Statisch 15 Min. 15 Sek. Statisch Prot. Auf Immer Schnell
Schalter Nr.	B3,1 B3,2 B3,4 B3,4 B3,5 B3,7 B3,7
Funktion	Ton Aus mit Prot. zu Ton Ein Lüfter Nachlaufzeit Xenon Nahclaufzeit Filmriß Ausgang Filmriß Ausgang Formatwechsel

B3,1 Funktion geändert ! B3,1 OFF = Keine Tonformatänderung mit Prot. zu. Ton Aus kommt dann nur bei Filmriß mit Prot. Auf.

全国**基**域。2018年2月 2月

STE15 Nr. 37-095.05

Program 5C31

Dipswitches B3,1 - B3,8

Pulse Pulse No Pulse Static 15 min. 15 sec. Static Frot. Open every time fast ŏ Switch No. B3,1 B3,2 B3,3 B3,4 B3,5 B3,7 B3,7 Sound Off/Prot.closed Sound On Function

) stati Impuls p. OFF = auch bei Vorla I immer mit Motor ein schnell langsam

15Sec

Impuls Impuls SMin 3Hin

stati.

stati. 15Min

> B3,1 Function changed!
> B3,1 Off = No Soundformat change with Prot. closed.
> Sound Off only with Filmtear with Prot. closed Formatchange Running-in period

Filmtear Output Filmtear Output Fan Delay Xenon Delay

Motor On w. Motor On normal

3 min.

Pulse

