



Film-Tech

The information contained in this Adobe Acrobat pdf file is provided at your own risk and good judgment.


These manuals are designed to facilitate the exchange of information related to cinema projection and film handling, with no warranties nor obligations from the authors, for qualified field service engineers.

If you are not a qualified technician, please make no adjustments to anything you may read about in these Adobe manual downloads.

www.film-tech.com



AM-1031 SYSTEM CABINET



AM-1031 SYSTEM CABINET

- G-1946 Cabinet
- G-1948 Cover, Molding and Door Strikes

- H-2714 Door Catch-Strike Fastening Screw (8)
- H-3101 Nameplate Fastening Screw (2)
- H-3226 Door Catch-Strike Fastening Nut (8)
- H-3255 Pivot-Slide Fastening Nut (24) *
- H-3441 Door Catch-Strike Lockwasher (8)

- P-1238 Pivot-Slide Lockwasher (24) *
- P-1266 Door Strike (2)
- P-1267 Door Catch (2)
- P-2155 Left Chassis Slide (4) *
- P-2156 Right Chassis Slide (4) *
- P-2160 Right Slide Top Lever (4) *
- P-2161 Chassis Slide Spacer (16) *
- P-2163 Front Slide Stop Screw (8) *
- P-2164 Rear Slide Stop Screw (8) *
- P-2165 Chassis Pivot Screw (8) *
- P-2167 Stop Lever Fastening Screw (8) *
- P-2174 Cover Molding (4)
- P-2236 Chassis Pivot Screw Spacing Washer (8) *
- P-2278 Left Slide Stop Lever (4) *
- P-2279 Cabinet Brace (3) *
- P-2765 Nameplate

* THE CABINET IS SHIPPED WITH THE TOP SECTION UNEQUIPPED AND THEREFORE INCLUDES ONLY 18 H-3255 AND P-1238; 3 P-2155, P-2156 AND P-2160 AND P-2278; 12 P-2161; 6 P-2163, P-2164, P-2165, P-2167 AND P-2236; AND 2 P-2279. THE PARTS TO EQUIP THE TOP SECTION ARE INCLUDED IN THE CABINET KITS.