## FILM-TECH

THE INFORMATION CONTAINED IN THIS ADOBE ACROBAT PDF FILE IS PROVIDED AT YOUR OWN RISK AND GOOD JUDGMENT.

THESE MANUALS ARE DESIGNED TO FACILITATE THE EXCHANGE OF INFORMATION RELATED TO CINEMA PROJECTION AND FILM HANDLING, WITH NO WARRANTIES NOR OBLIGATIONS FROM THE AUTHORS, FOR QUALIFIED FIELD SERVICE ENGINEERS.


IF YOU ARE NOT A QUALIFIED TECHNICIAN, PLEASE MAKE NO ADJUSTMENTS TO ANYTHING YOU MAY READ ABOUT IN THESE ADOBE MANUAL DOWNLOADS.

WWW.FILM-TECH.COM


**KELMAR** Systems Inc., 284 Broadway, Huntington Station, NY 11746 • 631.421.1230 • FAX 631.421.1274 Electric Changeover Instructions

## **Basic Assembly Detail**

Mounting Details for ECS35/70




## <u>Universal Bell Crank</u>



<u>Use appropriate holes as shown for proper</u> <u>clearance, geometry and dowser travel</u>

## Orientation of XL Douser Link




Green	-	Ground
White	-	Common
Black	-	Open
Red	-	Close

This End Attaches to Douse:

Remove the Old Connector from the Douser F Then Insert this End and Secure wit #4 Washer and Cotter Pin.






 15
 8611191
 Cover

 16
 SP6P1/4
 Screw, 6-32 x .250 Phillips Pan Head (4)

Page 2

M





Page 3