

Film-Tech

The information contained in this Adobe Acrobat pdf file is provided at your own risk and good judgment.

These manuals are designed to facilitate the exchange of information related to cinema projection and film handling, with no warranties nor obligations from the authors, for qualified field service engineers.

If you are not a qualified technician, please make no adjustments to anything you may read about in these Adobe manual downloads

www.film-tech.com

SONY®

SDDS Player System

DIGITAL FILM SOUND READER

DFP-R2000

DIGITAL FILM SOUND DECODER

DFP-D2000

USER GUIDE

1st Edition

Introduction – general use

The SDDS sound format

SDDS (Sony Dynamic Digital Sound) is designed to reproduce up to 8 channels of high quality audio in cinema theatres.

The audio data is stored on the film strip, on both outer edges, outside the perforation holes. The SDDS track is printed in the cyan colour layer of the film, and will appear as small pixels in a blueish or greenish colour.

The two tracks are called the P-track and S-tracks, indicating which is closest to the picture and which is closest to the conventional analogue sound track.

A unique SDDS back-up feature makes it possible for the system to play with one track only over short periods without any audible artefacts.



The DFP-2000 System


The DFP-D2000 has been designed to play back SDDS digital sound tracks in cinemas already equipped with cinema processors for playback of other sound formats.

As the last sound processor in the audio chain prior to the power amplifiers and/or crossover networks, the DFP-2000 decoder acts like a gate that keeps the signal flow from the central cinema processor open as long as no SDDS data is detected.

The moment SDDS data is decoded, this gate for the central cinema processor (referred to as "bypass inputs") is closed. Instead the gate for the SDDS audio is opened so that the SDDS audio is routed to the power amplifiers and speakers.

As soon as the SDDS data stream stops, the DFP-2000 will switch back to the bypass inputs. This state is referred to as "soft bypass" to distinguish it from the state, where the operator actively presses the bypass button on the front panel, forcing the DFP-2000 to "hard bypass". In this hard bypass mode, the SDDS decoder will not resume SDDS playback unless the bypass button is pressed again. The same can be accomplished by switching off the mains power of the DFP-2000.

The playback mode (SDDS or soft bypass) can be checked by monitoring the Data present indicator on the front panel.



If the Data present indicator is off, the film is not running through the reader at the right speed.

If it is flashing, the film is running, but no SDDS data can be decoded.

When it is solidly on, the unit plays back SDDS through the sound system unless the bypass button has been activated (button is lit).

The mute button can be activated to stop the SDDS playback and achieve complete silence. However, the button is only relevant if the bypass button is not activated.

Master level control

The master level control is calibrated in true dB steps. 0.0 dB is the reference level and will match fader-setting 7.0 on most other cinema processors.

Below is a table for level setting comparisons between the SDDS decoder and other common cinema processors.

To make sure that the playback level is uniform during your entire show, please ensure that the master level control of the other cinema processor is always set to a level, which matches the selected SDDS playback volume according to this table.

Note that this level comparison will only be correct if all systems are correctly set-up and aligned.

SDDS	Others
+ 10.0	10
+ 6.6	9
+ 3.3	8
0.0	7
- 3.3	6
- 6.6	5
- 10.0	4

← Reference level, calibrated to 85 dBC


Please note: The DFP-2000 level scale is limited to +/- 10 dB. If -10 dB is not sufficient attenuation to achieve a comfortable listening level, contact your service personnel to check that your system is correctly aligned.

Maintenance

Reader

The SDDS reader lenses and the light source fibre optics must be kept clean at all times. A combination of using a blower brush and cotton buds is recommended for this purpose. See the SDDS Quick Reference Guide for further details about cleaning the SDDS optics.


Additionally, the entire reader film path must be kept clean at all times. All surfaces marked grey on the below illustration will touch the film and must therefore be free from dust.



Decoder

The air intake filter of the SDDS decoder must be kept clean at all times to avoid that clogging stops the airflow.

Open the front panel of the DFP-2000 decoder and remove the air filter in the front panel door, clean it and re-insert it.



How often this must be done depends on the density of dust in the air in your projection room.

A clean working environment will contribute to making this procedure necessary on a quarterly basis only.

Service procedure

The following service procedure is required and should be performed yearly by your qualified service personnel.

- Checking and adjusting the Video level of the SDDS reader, changing LED's if necessary.
- Checking the SDDS error rate using a calibrated SDDS alignment film.
- Confirming that all reader rollers and other mechanical parts are in working order and replace if necessary
- Check that the channel levels and frequency response are correct
- Securing system settings and replacing the SRAM battery (every 2nd year only)

Troubleshooting


If the SDDS playback is unstable (i.e. the DFP-2000 switches frequently between SDDS playback and playback of the bypass inputs), press the bypass button to avoid that the switching is compromising the film presentation.

After the show, always check with known good SDDS film material to verify whether the problem was print- or system related.

It is recommended to always keep a loop of the SDDS alignment film at hand (alternatively another loop of film with good SDDS data blocks) for this purpose.

Make sure that the reader lenses and the light source fibre optics are clean before playing your SDDS test loop.

Then open the hinged front panel door of the DFP-2000 and monitor the bank of red LED indicators. D3 and D4 indicate the condition of the S-track and P-track on the film respectively.



With a good SDDS print played on a fully working SDDS system, these two LED's should be on all the time, apart from through splices. Frequent dark bursts indicate a faulty print or a faulty SDDS system.

With your SDDS reference loop, the LED's should stay on at all times apart from through the splice. If this is not the case, please contact your qualified service personnel to have your SDDS system checked.

If the system works normally with your reference film, but fails during the show, contact your print provider to let them know that they have delivered a faulty print. SDDS tracks are very resilient from wear and tear, and print problems are most likely caused by issues with the printing or subtitling process. Therefore, it is instrumental that you let your print provider/film distributor know to make sure that such issues are resolved.

Additionally, you may fill in the SDDS Film Print Form and send to Sony to make us able to provide technical assistance to the relevant laboratory.