

Film-Tech

The information contained in this Adobe Acrobat pdf file is provided at your own risk and good judgment.

These manuals are designed to facilitate the exchange of information related to cinema projection and film handling, with no warranties nor obligations from the authors, for qualified field service engineers.

If you are not a qualified technician, please make no adjustments to anything you may read about in these Adobe manual downloads

www.film-tech.com

*** UA BAR CODE SCANNER RETRO-FIT RELAY SCHEDULE ***

BAR CODE	RELAY # ACTIVATED	FUNCTION
C23	K1	CROSS CUE (FEATURE)
I24	K2	INBOARD CUE (LIGHTS UP)
O22	K3	OUTBOARD CUE (SHOW END)
X35	K4	SPARE (USER ASSIGNED)
99	K5	FAILSAFE * ARM FLAG CODE

* LATCH OUTPUT, RELAY ENERGIZED WITH CODE 99 SCANNED.

TERMINATIONS:

1	K1 FEED
2	K1 OUTPUT
3	K2 FEED
4	K2 OUTPUT
5	K3 FEED
6	K3 OUTPUT
7	K4 FEED
8	K4 OUTPUT
9	FAILSAFE N.C. [K5]
10	FAILSAFE N.O. [K5]
11	FAILSAFE FEED [K5]
12-13	GROUND (BOARD FEED)
14-15	12 VAC (BOARD FEED)

TO REPLACE KELMAR TYPE CUE DETECTOR ADD JUMPER TERMINALS:

1-3-5-7-11-12 CONNECT 12 VAC FEED TO TERMINALS 13, 14
TERMINAL #2 CROSS CUE, #4 INBOARD CUE, #6 OUTBOARD CUE